

Quick Start FIS-6800 Industrial Scanner





wenglor sensoric gmbh

wenglor Straße 3 88069 Tettnang ≅ +49 (0)7542 5399-0 info@wenglor.com

Weitere wenglor Kontakte finden Sie unter: For further wenglor contacts go to: Autres contacts wenglor sous:

www.wenglor.com

Änderungen vorbehalten Right of modifications reserved Modifications réservées 01.04.2010

Step 2 — Connect the System

Important: When connecting Ultra-Lock cordsets to the FIS-6800 and AB-0830, align the pins first and then push the connector into place. <u>Do not twist</u> the connectors, as this will bend the pins.

Important: Do not attempt to power more than four imagers with a single power supply in a daisy chain configuration. Add a AB-0830 and one power supply for every four additional imagers in the daisy chain.

RS-232

- Connect the Serial Communication Cable from "A" on the FIS-6800 to "2" on the AB-0830.
- Connect the host cable from "1" on the AB-0830 to the host computer.
- 3. Connect the photo sensor to "T" on the AB-0830.
- 4. Connect the power supply to "3" on the AB-0830.
- 5. Plug in the power supply.


Ethernet

- Connect the Ethernet Cable from "B" on the FIS-6800 to the network.
- 2. Connect the power supply to "A" on the FIS-6800.
- 3. Connect the photo sensor to "T" on the AB-0830.
- 4. Plug in the power supply.


Step 3 — Position the Scanner

- Position the scanner at a focal distance of one inch or more from a test symbol.
- Tip the scanner relative to the symbol to avoid the glare of direct (specular) reflection. The case parting line should be perpendicular to the plane of the symbol by either pitching the symbol or the imager as shown.
- 3. Symbols can be rotated (tilted) at any angle; however, for best results symbols should be aligned with the field of view. In the case of linear symbols, aligning the bars in the direction of their movement (ladder orientation) will minimize the chances of blurring and will result in more consistent decodes.

Important: Avoid excessive skew or pitch. Maximum skew is $\pm 30^\circ$; maximum pitch is $\pm 30^\circ$. The illustration below shows skew axis, pitch axis, and tilt axis.



Step 1 — Check Hardware



Hardware Required

Caution: Be sure that all connections are secure **BEFORE** applying power. Power down **BEFORE** disconnecting any cables.

Item	Description	Part Number
1	FIS-6800 Industrial Scanner	FIS-6800-XXXXG-01
2	AB-0830 Interface Device	AB-0830
3	Cordset, Common, M12 12-pin Plug to M12 12-pin Socket	ZAV12Rx01
5	Cordset, Host, Serial, M12 12-pin Socket to DB9	ZAV13Rx01
6	Power Supply, M12 12-pin Socket, 1.3 m	NT-10
7	Cordset, Host, Ethernet, M12 8-pin Plug to RJ45	ZAV88Rx01
8	Photo Sensor, M12 4-pin Plug	

Note: Additional cordsets and accessories are available in the Microscan Product Catalog.

Step 4 — Install ESP

ESP Software can be found on the wenglor Software CD ZUB-CD-BS that is packaged with the FIS-6800.

- 1. Follow the prompts to install ESP from the CD.
- 2. Click on the ESP icon to run the program.



Note: ESP can also be installed from the **Download** Center at www.wenglor.com.

Minimum System Requirements

- 166 MHz Pentium processor (Pentium II processor recommended)
- Windows Vista, XP, or 2000 operating system
- Internet Explorer 5.0 or higher
- 64 MB minimum RAM (128+ MB RAM recommended)
- 80 MB hard drive space
- 800 x 600 minimum 256 color display (1024 x 768 32-bit color recommended)

Refer to the FIS-6800 Industrial Scanner User's Manual for detailed information about using ESP to configure the FIS-6800.

Step 5 — Select Model

When you start ESP, the model menu will appear:



- Click the button showing the FIS-6800.
- 2. Click OK.

Note: You can also simply double-click the button showing your imager to make your selection.

3. Click **Yes** when the following dialog appears:



Note: If you need to select another model later, click the Switch Model button near the top of the screen or use Model > New Model in the menu toolbar.

Step 6 — Connect


To connect using the Connection Wizard:

- ‡ Click Connect on the menu toolbar, and then select Connection Wizard.
- ‡ Select **RS-232** or **Ethernet** to activate the appropriate display.
- ‡ Configure settings as required by the application, and click **Connect**.





‡ When a connection is established, the green indicator in the status bar at the bottom right of the screen will be visible:



Important: The imager is in **Continuous Read Mode** by default. For best connection results, be sure that no decodable symbols are within the imager's field of view while attempting to connect.

Step 7 — Locate Symbol

Locate by ESP

In ESP's EZ Mode, click the Locate button to enable the red X pattern.

The symbol in the field of view will appear in the video view beneath the **Locate** and **Calibrate** buttons, and you will see the red target pattern projected from the front of the scanner.

‡ Center the target pattern on the symbol.

Important: The entire symbol should fall within the field of view (FOV) of the scanner. The field of view is what appears in ESP's Locate/Calibrate window in EZ Mode.

‡ Click the **Stop** button to end the **Locate** function.



Locate by EZ Button

If you are not connected to a host computer, the EZ Button allows you to locate the symbol in the scanner's field of view.

- ‡ Hold down the EZ Button for about one second and release when you hear one short beep. The amber 20 % LED will illuminate, and you will see the red target pattern projected from the front of the scanner.
- ‡ Center the target pattern on the symbol.

Note: To end all EZ Button functions, press the EZ Button once and quickly release.

Step 8 — Calibrate

Scanner settings can be adjusted automatically for optimum performance by either the EZ Button or by **ESP**.

During the calibration routine, the scanner will flash its Read Rate percent LEDs and illumination LEDs while searching camera settings and determining the best configuration for decoding symbol data. Upon successful completion of this routine, a green LED pattern will flash brightly and illuminate the symbol. If unsuccessful, the scanner will emit 5 short beeps and stop searching.

Calibrate by ESP

- Click the Calibrate button.
- 2. The scanner will search camera settings to determine the best configuration for decoding symbol data. A successful calibration will display a green frame around the symbol, and the following message will appear: "Uploading all reader parameters." After a moment the symbol data will be presented in the field below the image display window.

Calibrate by EZ Button

- Hold down the EZ Button for about two seconds and release when you hear two short beeps. The 20 % and 40 % LEDs on the top of the unit will illuminate.
- The scanner will search camera settings to determine the best configuration for decoding symbol data.

 The scanner will ST purchase the ST purchase t

Note: To end all EZ Button functions, press the EZ Button once and quickly release.

Calibrate by Serial Command

Send <@CAL> from a terminal program to begin auto-calibration.

Step 9 — Test Read Rate

Read Rate indicates the number of successful decodes per second achieved by the scanner.

Test Read Rate by ESP

1. Click the **Test** button to start the **Read Rate** test.



If a symbol has been successfully decoded, its data and related information will be presented in the field below the image display window. While the symbol is being decoded, the Read Rate LEDs will indicate the read rate percentage on the top of the unit.

2. Click the **Stop** button to end the Read Rate test.

Note: Read rate can also be tested using the Read Rate interface in **Utilities**.

Test Read Rate by EZ Button

- To start the Read Rate test, hold down the EZ Button about three seconds until you hear three short beeps. The 20 %, 40 %, and 60 % LEDs on the top of the unit will illuminate.
 - While the symbol is being decoded, the Read Rate LEDs will indicate the read rate percentage on the top of the unit.
- To end the Read Rate test, press the EZ Button and quickly release.

Test Read Rate by Serial Command

You can also start a test with the <C> or <Cp> command and end it with the <J> command.

Step 10 — Configure and Save

Click the **App Mode** button to make configuration changes.



The following modes are accessible by clicking the buttons at the top of the screen:



- ‡ Click the **EZ Mode** button to return to EZ Mode.
- Click the Autoconnect button to establish communication.
- ‡ Click the **Send/Recv** button to send or receive commands.
- ‡ Click the **Switch Model** button to open the model menu.
- Click the Parameters button to show the tree controls for Communication, Read Cycle, Symbologies, I/O Parameters, Symbol Quality, Matchcode, and Diagnostics.
- Click the Setup button to access the Camera Setup tree and the interfaces for Video, Evaluation, Calibration, Window of Interest (WOI), Configuration Database, Ordered Output, Output Format, and Dynamic Setup.
- ‡ Click the Terminal button to display decoded symbol data, and to send serial commands to the imager using text or macros.
- ‡ Click the **Utilities** button to show the tabbed interfaces for Read Rate, Counters, Device Control, Differences from Default, Master Database, and Firmware.

Saving Options

- # Send, No Save. Changes will be lost when power is re-applied to the scanner.
- **\$ Send and Save.** This activates all changes in current memory and saves to the scanner for power-on.