

# OCPxxxP0150P

High-Performance Distance Sensor



**PROFI**  
**NET**

Operating instructions

## Index

<b>1. Use for Intended Purpose</b>	<b>4</b>
<b>2. Safety Precautions</b>	<b>4</b>
2.1. Safety Precautions	4
2.2. Laser/LED Warnings	4
2.3. Approvals and IP Protection	4
<b>3. Device Features</b>	<b>5</b>
3.1. Connection Diagram	7
3.2. Housing Dimensions	7
3.3. Control Panel	8
3.4. Complementary Products	8
<b>4. Mounting Instructions</b>	<b>8</b>
<b>5. Initial Operation</b>	<b>9</b>
5.1. Initial Operation	9
5.2. Default Settings	9
<b>6. Functional Overview OLED-Display</b>	<b>10</b>
6.1. Run	12
6.2. Display	12
6.2.1. Display Mode	12
6.2.2. Display Intensity	13
6.3. Offset	13
6.4. Resolution	14
6.5. Filter	14
6.6. Exposure	14
6.8. Laser	15
6.9. I/O Test	15
6.10. Network	16
6.11. Language	17
6.12. Info	17
6.13. Reset	17
6.14. Password	18
<b>7. Information on PROFINET</b>	<b>19</b>
<b>8. Network Settings</b>	<b>24</b>

<b>9. Web-based configuration</b>	<b>24</b>
9.1. Invoking the Management Interface	24
9.2. Page layout	25
9.3. Device general	26
9.4. Device Settings	27
9.5. Measured Value Settings	28
9.6. Device Test	29
<b>10. Maintenance Instructions</b>	<b>29</b>
<b>11. Proper Disposal</b>	<b>29</b>
<b>12. EU Declaration of Conformity</b>	<b>29</b>

## 1. Use for Intended Purpose

This wenglor product must be used in accordance with the following functional principle: High-performance distance sensors which use the principle of angle measurement determine the distance between the sensor and the object. These sensors have small working ranges (under 1 m) and recognize objects with high precision. Some sensors use a high-resolution CMOS line array and DSP signal processing. The color, shape and texture of the objects to be recognized does not affect the sensors' measurements. Even dark objects can be reliably detected against a bright background. They can be operated with very high speeds or very high resolutions. The measured value can be output as an analog value or via the interfaces. Furthermore, Teach-In, filter functions for adjusting a switching output, and an error output are available. The measuring range can be selected individually within the working range.

## 2. Safety Precautions

### 2.1. Safety Precautions

- This operating instruction is part of the product and must be kept during its entire service life
- Read this operating instruction carefully before using the product
- Installation, start-up and maintenance of this product has only to be carried out by trained personal
- Tampering with or modifying the product is not permissible
- Protect the product against contamination during start-up
- Not a safety component in accordance with the EU Machinery Directive.

### 2.2. Laser/LED Warnings



**Laser class 1 (EN 60825-1)**  
Standards and safety instructions must be observed.

### 2.3. Approvals and IP Protection







### 3. Device Features

Order No.	OCP801P0150P	OCP162P0150P	OCP352P0150P	OCP662P0150P
Working Range	30...80 mm	40...160 mm	50...350 mm	60...660 mm
Measuring Range	80 mm	160 mm	350 mm	660 mm
Reproducibility	15...50 $\mu\text{m}$	20...70 $\mu\text{m}$	20...150 $\mu\text{m}$	70...1000 $\mu\text{m}$
Linearity Deviation	50...100 $\mu\text{m}$	50...160 $\mu\text{m}$	100...500 $\mu\text{m}$	100...1000 $\mu\text{m}$
Temperature Drift	<5 $\mu\text{m/K}$	<10 $\mu\text{m/K}$	<20 $\mu\text{m/K}$	<50 $\mu\text{m/K}$
Output Rate	330/s			
Light Source	Laser (red)			
Wave Length	655 nm			
Service Life (T = 25 °C)	100000 h			
Laser Class (EN 60825-1)	1			
max. Ambient Light	10000 Lux			
Beam Divergence	< 2 mrad			
Light Spot Diameter	3.6 × 0.9 mm			
Port Type	100BASE-TX			
PoE Class	1			
Temperature Range	-25...50 °C			
Reverse-polarity Protection	Yes			
Interface	PROFINET			
Protection Class	III			
Adjustment	Menu (OLED)			
Housing material	Metal			
Protection Class	IP68			
Connection Type	M12×1, 8-pin			
Control Panel No.	X2, T12			
Webserver	Yes			
PROFINET IO, CC-B	✓			





Reference material: kodak white 90 % remission

The warm-up phase lasts approx. 30 minutes. At the beginning of this time, the linearity deviation and reproducibility may vary by a factor of up to 10. During the warm-up phase the values improve in the form of an exponential function until the technical data is reached.

## Typical Reproducibility Curves within the Working Range




## Typical Linearity Error Curves within the Working Range




## 3.1. Connection Diagram

001




### Legend

+	Supply Voltage +
-	Supply Voltage 0 V
~	Supply Voltage (AC Voltage)
A	Switching Output (NO)
$\bar{A}$	Switching Output (NC)
V	Contamination/Error Output (NO)
$\bar{V}$	Contamination/Error Output (NC)
E	Input (analog or digital)
T	Teach Input
Z	Time Delay (activation)
S	Shielding
RxD	Interface Receive Path
TxD	Interface Send Path
RDY	Ready
GND	Ground
CL	Clock
E/A	Output/Input programmable
	IO-Link
PoE	Power over Ethernet
IN	Safety Input
QSSD	Safety Output
Signal	Signal Output
BL-D+/-	Ethernet Gigabit bidirect. data line (A-D)
EN0RS42Z	Encoder 0-pulse 0-0 (TTL)

PT	Platinum measuring resistor
nc	not connected
U	Test Input
$\bar{U}$	Test Input inverted
W	Trigger Input
W-	Ground for the Trigger Input
O	Analog Output
O-	Ground for the Analog Output
BZ	Block Discharge
AwV	Valve Output
a	Valve Control Output +
b	Valve Control Output 0 V
SY	Synchronization
SY-	Ground for the Synchronization
E+	Receiver-Line
S+	Emitter-Line
$\pm$	Grounding
SrR	Switching Distance Reduction
Rx+/-	Ethernet Receive Path
Tx+/-	Ethernet Send Path
BuB	Interfaces-Bus A(+)/B(-)
La	Emitted Light disengageable
Mag	Magnet activation
RES	Input confirmation
EDM	Contact Monitoring


EN0RS42Z	Encoder A/A (TTL)
EN0BS42Z	Encoder B/B (TTL)
ENA	Encoder A
ENB	Encoder B
AMIN	Digital output MIN
AMAX	Digital output MAX
ADK	Digital output OK
SY In	Synchronization In
SY OUT	Synchronization OUT
0LT	Brightness output
M	Maintenance
rsv	reserved
Wire Colors according to IEC 60757	
BK	Black
BN	Brown
RD	Red
OG	Orange
YE	Yellow
GN	Green
BU	Blue
VT	Violet
GY	Grey
WH	White
PK	Pink
GNYE	Green/Yellow

## 3.2. Housing Dimensions



1 = Transmitter Diode  
2 = Receiver Diode

3.3. Control Panel



Designation	Condition	Function
CS (Communication Status)	Off	Connection (AR) with controller established
	Green	Protocol not initialized
	Red	No connection (AR) with controller established
MS (Modul Status)	Red	Error (class FATAL)
	Red flashing	Detection function, may be activated via Engineering Tool
L/A	Green	Links present
	Green flashing	Communication

3.4. Complementary Products

wenglor offers Connection Technology for field wiring.

Suiting Mounting Technology No. 380

Suitable Connection Technology No. 50

Midspan Adapter Z0029

Switch with PoE ZAC50xN0x

4. Mounting Instructions

When using the Sensor, follow the corresponding electrical and mechanical regulations, standards and safety rules. The Sensor must be protected against mechanical influence. The Sensor has optimum extraneous light qualities when the background is within the working range.

## 5. Initial Operation

### 5.1. Initial Operation

Each Ethernet device has a unique MAC address. With wenglor you can find the MAC address on the type plate of the device.

In the default settings, the device has the following IP-Address 192.168.100.1. You can access the website of the device via the IP-Address. You can change settings on the device on the website or using the OLED display in order to test applications.

**Caution:** In the case of operation on a control unit, settings that were changed on the website or using the OLED display will be overwritten by the control unit.

If you want to start up the device on a control unit, please perform the following steps:

- Connect the Sensor to a switch with PoE using an appropriate cable M12×1; 8-pin. In the case of a switch without PoE, please use the Midspan Adapter (Z0029) for the appropriate voltage supply. When the voltage supply is present, the display on the Sensor starts.
- Install the associated device-specific electronic description file (e.g. for PROFINET, the GSDML file) in the hardware manager. You can find the file you require for download at [www.wenglor.com](http://www.wenglor.com) → **Products** → **Product search** (order number). Explanations regarding the electronic description file and its structure can be found in the detailed operating instructions in PDF format.
- Help on installing the file in the control and design of the network can be found in the help files of the relevant control. wenglor provides a description for the download at: [www.wenglor.com](http://www.wenglor.com) → **Products** → **Product search** (order number).

### 5.2. Default Settings

		OCPxxxP0150P
Display	Mode	Process
	Intensity	Screensaver
Offset	Default Offset	0 mm
Filter		1
Resolution		High
Exposure		DCM
Output Rate		Normal
Laser		ON
Network	IP-Address	192.168.100.1
	Subnet Mask	255.255.255.0
	DHCP	DHCP OFF
	Std Gateway	192.168.100.254
	MAC Address	(See type plate on the product)
Language		English
Password	Activate	Off
	Change	0

6. Functional Overview OLED-Display






Fig. 1: Set language menu

#### Navigation by pressing the button:

- ▲ : Navigation up.
- ▼ : Navigation down.
- ↵ : Enter Button.

The selection is confirmed by pressing the Enter button.

#### Meaning of the menu items:

- ◀ Back : one level higher in the menu.
  - ◀◀ Run : Switch to display mode.
- Change to the configuration menu by pressing any button.

**Note:** If no setting is made in the configuration menu for a period of 30 s, the Sensor returns automatically to the display view.


Pressing the button again returns the Sensor to the last menu view used. If a setting is made, it becomes active once you leave the configuration menu.

**Important:** To prevent any damage to the buttons, please do not use any pointed objects for setting.

The following explains the functions behind the individual menu items.

6.1. Run

The Sensor switches into display mode.



Symbol descriptions of status LEDs:

Symbol	Significance	State 1	State 2	State 3
Symbol 1	Warm-up	ok	wait	–
Symbol 2	Signal Strength	ok	too low (dirty)	too high
Symbol 3	Temperature	ok	too high	too low

6.2. Display

Display	Adjust the display device
Mode	<b>Mode:</b> Select display mode (see chapter 7.2.1)
Rotate	<b>Rotate:</b> Rotate display by 180°. By pressing the “←” button the display is rotated by 180°. The rotation is canceled by pressing this button again.
Intensity	<b>Intensity:</b> Set the display intensity (see chapter 7.2.2)
◀ Back	
⏪ Run	

6.2.1. Display Mode

The measured value in mm and the PROFINET device name always appear in the Sensor’s display. [offline] will be displayed here unless the PROFINET device name has been changed. You can choose from the following additional displays in the menu item “display mode”:

Mode	Adjust the display device
○ Process	<b>Process:</b> Display of status LEDs for warm-up, signal strength and temperature.
○ Text	<b>Text:</b> Display of a free text that can be sent to the Sensor via the control.
○ Analysis	<b>Analysis:</b> Display of signal strength in percent and measuring rate in 1/s.
○ Network	<b>Network:</b> Display of the PROFINET LEDs MS, CS and L/A. For the function of these LEDs, see “4.3. Control Panel” on page 8.

### 6.2.2. Display Intensity

Intensity	Set the display intensity	
<input type="radio"/> Min	<b>Min:</b>	The intensity of the display is set to a minimum value.
<input type="radio"/> Normal	<b>Normal:</b>	The intensity of the display is set to a medium value.
<input type="radio"/> Max	<b>Max:</b>	The intensity of the display is set to a maximum value.
<input type="radio"/> Power save	<b>Power save:</b>	The display switches off after one minute without a button being pressed and automatically switches back on when a button is pressed.
<input type="radio"/> Screensaver	<b>Screensaver:</b>	The colors of the display are inverted every minute.

### 6.3. Offset


The offset function is used to change the current measured value to a defined value.

Offset	Change the measured value	
Default Change Apply ◀ Back ⏪ Run	<b>Default:</b>	Learn offset value. The current measured value is adopted as the default offset value by pressing the “T”. The offset value is set to 0 by pressing the “Z” button.
	<b>Change:</b>	Change the value of the offset. By pressing the “+” button or the “-” button, the value set in the menu item “Default” can be changed.
	<b>Apply:</b>	Accept the offset value set in the menu item “Default” as the measured value. By pressing the “T” button, the offset value set in the menu item “Default” is adopted as the displayed measured value. The offset function is reset by pressing the “Z” button, and the actual distance is displayed.

The currently set default offset value is displayed in  $\mu\text{m}$ .

#### Example of the measured value for the offset function:

In the diagram the Sensor measures a distance of 500 mm. After application of the offset with offset value of 0 mm, the measured value at 500 mm becomes the measured value 0 mm.



6.4. Resolution

The number of pixels used by the CMOS line is defined by the resolution. The higher the resolution set, the smaller the detectable movements of an object and the slower the output rate of the Sensor becomes when there is a change in the measured values.

Resolution	Adjust the display device
<div><div><div><div></div></div><div>High</div></div><div><div><div></div></div><div>Medium</div></div><div><div><div></div></div><div>Low</div></div><div><div><div></div></div><div>Back</div></div><div><div><div></div></div><div>Run</div></div></div>	<div><div><div>High:</div><div>High resolution, low output rate</div></div><div><div>Medium:</div><div>Medium resolution, medium output rate.</div></div><div><div>Low:</div><div>Low resolution, high output rate.</div></div></div>

6.5. Filter

The filter (filter size) is the number of measured values over which the Sensor takes an average. The larger the filter selected, the slower the response time of the Sensor becomes when there is a change in the measured values. A larger filter improves the reproducibility of the Sensor.

Filter	Number of values for averaging
<div><div><div><div></div></div><div>1</div></div><div><div><div></div></div><div>2</div></div><div><div><div></div></div><div>5</div></div><div><div><div></div></div><div>10</div></div><div><div><div></div></div><div>20</div></div><div><div><div></div></div><div>50</div></div><div><div><div></div></div><div>100</div></div><div><div><div></div></div><div>Back</div></div><div><div><div></div></div><div>Run</div></div></div>	<div><div>If 1 is selected, each measured value is output directly without averaging. When-</div><div>ever a value greater than 1 is selected, the Sensor takes an average over the</div><div>selected number of x measured values.</div></div>

6.6. Exposure

The Sensor adjusts its exposure time or light pulse duration automatically up to a maximum value on the object to be detected. In the default DCM (Default Capture Mode), the Sensor has a fixed maximum possible exposure time. In the case of black or shiny objects, for example, it can be helpful to lengthen this time. It can be helpful to reduce the exposure time when the Sensor is aimed at the light source. In the case of problematic applications, it can be influenced by different modes or manually.

Exposure	Adjusting Exposure Times
<div><div><div><div></div></div><div>SCM</div></div><div><div><div></div></div><div>LCM</div></div><div><div><div></div></div><div>DCM</div></div><div><div><div></div></div><div>CCM</div></div><div><div><div></div></div><div>Back</div></div><div><div><div></div></div><div>Run</div></div></div>	<div><div><div><div>SCM (Short Capture Mode):</div><div>The Sensor exposure time can be shortened on dark or glossy objects (e.g. black varnish) in order to reduce a fall in the measuring rate.</div></div><div><div>LCM (Long Capture Mode):</div><div>The Sensor exposure time can be lengthened on dark or glossy objects (e.g. black varnish) in order to achieve a more accurate measurement.</div></div><div><div>DCM (Default Capture Mode):</div><div>Default exposure time for standard applications.</div></div><div><div>CCM (Custom Capture Mode):</div><div>The Sensor exposure time can be adjusted manu-</div><div>ally between 100...2000 <math>\mu</math>s.</div></div></div></div>

## 6.7. Output Rate

The output rate indicates how often the measured value is refreshed per second at the output.

Output Rate	Adjust Output Rate
<ul style="list-style-type: none"> <li>○ Normal</li> <li>○ Fast</li> <li>◀ Back</li> <li>◀◀ Run</li> </ul>	<p><b>Normal:</b> The normal output rate is 100/s. This means that a new measured value is read out every 10 ms.</p> <p><b>Fast :</b> The fast output rate is 330/s. This means that a new measured value is read out every 3 ms.</p> <p><b>Note:</b> If this mode is activated, the OLED display is switched off as soon as a PROFINET controller goes online. It's switch back on automatically when the controller goes offline again.</p>

## 6.8. Laser


In the menu item "Laser", the emitted light can be switched on or off.

Laser	Switch transmitted light on or off
<ul style="list-style-type: none"> <li>○ On</li> <li>○ Off</li> <li>◀ Back</li> <li>◀◀ Run</li> </ul>	<p><b>ON:</b> Switch transmitted light on</p> <p><b>OFF:</b> Switch transmitted light off; the Sensor no longer supplies measured values</p>

## 6.9. I/O Test

This function manually changes the output of the Sensor. As a result, it possible to test whether the further process is working as desired. The test is automatically terminated once you leave the test menu.

I/O Test	Test of the Sensor outputs
<ul style="list-style-type: none"> <li>Measured value</li> <li>Statusbits</li> <li>Warm-up</li> <li>Signal Strength</li> <li>Temperature</li> <li>◀ Back</li> <li>◀◀ Run</li> </ul>	<p><b>Measured value:</b> Default of a measured value in <math>\mu\text{m}</math></p> <p><b>Statusbits:</b> The number of the status bit to be set can be selected by pressing the "+" or "-" button. (see list of Statusbits)</p> <p><b>Warm-up:</b> Default of the warm-up on "ok" or "warm-up"</p> <p><b>Signal strength:</b> Default of the signal strength on "ok", "too low" or "too high"</p> <p><b>Temperature:</b> Default of the temperature on "ok", "too low" or "too high"</p>

If the Sensor returns to the display view after 30 seconds without pressing the button while the test is still active, this is indicated by a  in the display view.

List of status bits:

Number	Function	Description of when the bit is set	Measured value read-out
1	General error	One of the following bits is set.	—
2	Distance to object too small	The current measured value is below the working range.	Measuring range lower limit
3	Distance to object too large	The current measured value is above the working range.	Measuring range upper limit
4	No signal	The sensor does not detect an object within its working range.	Measuring range upper limit
5	Signal too weak	Too little light is reflected back to the sensor from the object (e.g. very dark surface). The quality of the measured value is reduced as a result.	Current measured value
6	Signal too strong	Too much light is reflected back to the sensor from the object (e.g. reflector) The quality of the measured value is reduced as a result.	Current measured value
7	Warm-up procedure	The sensor is currently in the warm-up phase and the quality of the measured value does not yet comply with the specified technical data. See page 5 below.	Current measured value
8	Temperature too high	The sensor is at the upper limit of its temperature range. If temperature continues to rise, the sensor may be destroyed.	Current measured value
9	Temperature too low	The sensor is at the lower limit of its temperature range. If temperature continues to drop, the sensor may be destroyed.	Current measured value

6.10. Network

Network	Settings of the Network Parameters	
IP-Address	IP-Address:	Display of the set IP-Address
Subnet Mask	Subnet Mask:	Display of the set Subnet Mask
DHCP	DHCP:	Display DHCP ON or DHCP OFF
Std Gateway	Std Gateway:	Display of the set standard gateway
MAC Address	MAC Address:	Display of the default MAC Address
Net Reset	Net Reset:	Reset network settings to the default settings
⬅ Back		
⬅⬅ Run		

## 6.11. Language

The menu language can be changed in the menu item "Language". The user is automatically prompted for his desired language at initial operation and after each reset.

Language	Set menu language
<ul style="list-style-type: none"> <li>○ Deutsch</li> <li>○ English</li> <li>○ Français</li> <li>○ Español</li> <li>○ Italiano</li> <li>◀ Back</li> <li>◀◀ Run</li> </ul>	The menu appears in the selected language immediately after selection.

## 6.12. Info

In the menu item "Info" the following information about the Sensor is displayed:

Info	
<ul style="list-style-type: none"> <li>Order number</li> <li>Software version</li> <li>Serial number</li> </ul>	

## 6.13. Reset

All Sensor settings, with the exception of the network settings, can be reset to the default settings in the menu item "Reset". The settings of the default settings can be found in Chapter "6.2. Default Settings" on page 9.

Reset	Reset to the default settings
Press <R> for Reset	The Sensor settings that have been made can be reset to the default settings by pressing the "R" button.

6.14. Password

Password protection prevents against changing the set data unintentionally.

Password	Set password functionality	
Activate Change Block ◀ Back ◀◀ Run	Enable:	Turn password protection on or off. If password protection is activated, the operation of the Sensor is disabled after supply power has been interrupted and is only enabled after successfully entering password.
	Change:	Change password.
	Lock:	Locking Sensor causes an immediate disabling of operation if activate Password is set to "on".

If the password functionality is activated, the password must be entered before each operation of the Sensor. After correctly entering the password by means of the "+" and "-" button, the menu is activated and the Sensor is operational.

- The password functionality is deactivated in the default settings.
- The value range of the password number ranges from 0000...9999

It is necessary to note the newly defined code before changing the password. A forgotten password can only be overwritten by a general password. The general password can be requested by sending an e-mail to [support@wenglor.com](mailto:support@wenglor.com).

## 7. Information on PROFINET

You can find the GSDML file for download at [www.wenglor.com](http://www.wenglor.com) → **Product World** → **Product search** (order number) → **Download**.

### 7.1. Overview of Device Access Point (DAP)

#### DAP

Modul-ID: 0  
Submodul: 0

Parameter:

Name	Data Type	Byte Offset	Bit Offset	Bit Length	Default Value	Value Range	Changeable	Index	Length	Description
Webserver Access	BitArea	0	0	1	0: enabled	0...1	Yes	300	1 Byte	0: enabled 1: blocked
Button lock	BitArea	0	0	1	0: enabled	0...1	Yes	301	1 Byte	0: enabled 1: blocked
Rotate display	BitArea	0	0	1	0: not rotated	0...1	Yes	302	1 Byte	0: not rotated 1: rotated
Display Intensity	BitArea	0	0	3	4: Screen-saver	0...4	Yes	303	1 Byte	0: Min 1: Normal 2: Max 3: Power saver mode 4: Screensaver
Display mode	BitArea	0	0	3	0: Process	0...3	Yes	304	1 Byte	0: Process 1: Analysis 2: Text 3: Network
Language	BitArea	0	0	3	1: English	0...4	Yes	305	1 Byte	0: Deutsch 1: English 2: Français 3: Español 4: Italiano
Offset Value	BitArea	0			0	-9999... 9999	Yes	308	4 Byte	

### 7.2. Overview of modules used in the DAP OCPxxxP0150P

Name	Cyclical Input	Parameter	Parameter Slot (pluggable)
Distance Value	Measured value, Status	Filter value, Laser ON OFF	1 (fix)
Status	Bit field	–	2 (fix)
Filter	Filter value	–	3 (pluggable)
Laser	Laser ON OFF	–	4 (pluggable)
Display text	Display text	–	5 (pluggable)
Offset	Offset Set	–	6 (pluggable)
Resolution	Resolution Mode	–	7 (pluggable)
Exposure	Exposure Mode	–	8 (pluggable)
Exposure Time	Max Exposure Time	–	9 (pluggable)

The detailed structure of the modules is described in the following.

Module Distance Value

Module ID: 1  
Submodule: 1  
Slot: 1

Format Cyclical Data:  
4 Byte Statusbits (see Module status)

Input	Output	Value Range	Data Type	Unit	Description
Measured value	–	–9999...9999	Integer32	10 µm	Distance Value
Statusbits	–	Bit	Unsigned32	–	(see Module status)

Parameter:

Name	Value Range	Data Type	Index	Presetting	Changeable
Filter	0...6	Unsigned8	257	0	Yes
Resolution	0...2	Unsigned8	258	0	Yes
Exposure Mode	0...3	Unsigned8	259	2	Yes
Exposure Time	100...2000	Unsigned16	260	1000	Yes
Laser	0...1	Bit	264	0	Yes

Module Status

Module ID: 2  
Submodule: 1  
Slot: 2

Format Cyclical Data:

Input	Output	Value Range	Data Type	Unit	Description
Statusbits	–	Bit	Unsigned32	–	Bit1: General Bit2: Distance to Object is too small Bit3: Distance to Object is too large Bit4: No signal Bit5: Contamination Bit6: Signal too high Bit7: Warm-up procedure Bit8: Overtemperature Bit9: Undertemperature

Parameter:

Name	Value Range	Data Type	Index
–	–	–	–

### Module Filter

Module ID: 3

Submodule: 1

Slot: 3

Format Cyclical Data:

Input	Output	Value Range	Data Type	Unit	Description
Filter Value	Filter Value	0...9	Unsigned8	–	0: filter size 1 1: filter size 2 2: filter size 5 3: filter size 10 4: filter size 20 5: filter size 50 6: filter size 100

Parameter:

Name	Value Range	Data Type	Index
–	–	–	–

### Module Laser ON OFF

Module ID: 4

Submodule: 1

Slot: 4

Format Cyclical Data:

Input	Output	Value Range	Data Type	Unit	Description
Laser ON-OFF	Laser ON-OFF	0...1	Unsigned8	–	0: Laser ON 1: Laser OFF

Parameter:

Name	Value Range	Data Type	Index
–	–	–	–

Module Display Text

Module ID: 5  
Submodule: 1  
Slot: 5

Format Cyclical Data:

Input	Output	Value Range	Data Type	Unit	Description
Display Text	Display Text	Text 19 Character	Visible String	–	Displayable Display Text

Parameter:

Name	Value Range	Data Type	Index
–	–	–	–

Module Offset

Module ID: 6  
Submodule: 1  
Slot: 6

Format Cyclical Data:

Output

Value Range	Data Type	Unit	Description
1...5	Unsigned8	–	0x00: Start command 0x01: Learn offset value 0x03: Reset offset value 0x04: Apply offset 0x05: Reset offset


Input

Value Range	Data Type	Unit	Description
0x00...0x10	Unsigned8	–	0x00: Ready for command 0x10: Command executed

Parameter:

Name	Value Range	Data Type	Index
–	–	–	–

Examples:



## Module Resolution

Module ID: 7

Submodule: 1

Slot: 7

Format Cyclical Data:

Input

Input	Output	Value Range	Data Type	Unit	Description
Resolution	Resolution	0...2	Unsigned8	–	0: Resolution high 1: Resolution medium 2: Resolution low

Parameter:

Name	Value Range	Data Type	Index
–	–	–	–

## Module Exposure Mode

Module ID: 8

Submodule: 1

Slot: 8

Format Cyclical Data:

Input

Input	Output	Value Range	Data Type	Unit	Description
Exposure Mode	Exposure Mode	0...3	Unsigned8	–	0: Mode SCM 1: Mode LCM 2: Mode DCM 3: Mode CCM

Parameter:

Name	Value Range	Data Type	Index
–	–	–	–

## Module Exposure Time

Module ID: 9  
Submodule: 1  
Slot: 9

Format Cyclical Data:

Input

Input	Output	Value Range	Data Type	Unit	Description
Exposure Time	Exposure Time	100...2000	Unsigned16	μs	Max Exposure Time

Parameter:

Name	Value Range	Data Type	Index
–	–	–	–

## 8. Network Settings

To operate the device in an Ethernet LAN, the device and the remote station, for example a computer, must be located in the same network. The IP-Address of the device is set to the IP-Address 192.168.100.1 and to the subnet mask 255.255.255.0 and standard gateway 192.168.100.254. In the instructions the default values are always assumed.

**WARNING:** It must be ensured that supply power is not interrupted while making changes to network settings. Furthermore, supply power must maintained for at least an additional 5 seconds after the network settings have been saved to memory.

## 9. Web-based configuration

The device is equipped with a web-based adjustment interface that works independent of the operating system. You can configure the device conveniently using a standard web browser (e.g. Internet Explorer or Firefox).

### 9.1. Invoking the Management Interface

Start the web browser. Enter the IP-Address of the device in the address line of your browser, and press the Enter button. The IP-Address is preset to 192.168.100.1.

Example: `http:\\192.168.100.1`



The overview page “Device general” is not password protected. If other pages are accessed, a password request appears. The following user data is preset in the default settings:

**User name:** admin  
**Password:** admin

The password can be changed on the “Device settings” page.

## 9.2. Page layout



**General device**

Part Number: OCP801P0150P  
 Product version: V1.0.0  
 Producer: wenglor sensoric GmbH  
 Description: OCP: Reflex Sensor with Background Suppression  
 Serial number: 000000000  
 MAC Address: 54-4a-05-06-01-66

Real-time Ethernet status: offline  
 Device name: [offline]

Measured value: 77.37 mm

The website is divided into the following 4 areas:

- 1. Language selection:** The website can be changed from English (default setting) to German, French, Spanish or Italian via the language selection.
- 2. Display:** On each page, the current display is represented exactly like on the device itself.
- 3. Category selection:** The web-based settings are divided into four categories:
  - **Device general:** Overview page with general information about the device
  - **Device settings:** Network and display settings of the device
  - **Measured value settings:** Settings for influencing the measured value of the device
  - **Device Test:** Manual change of the Sensor output in order to test the process
- 4. Page content:** Depending on which category is selected, the relevant page content is displayed.

9.3. Device general



Sensors for your success

English

General device

Device settings

Measured value settings

Device test

General device



Part Number	OCP801P0150P
Product version	V1.0.0
Producer	wenglor sensoric GmbH
Description	OCP: Reflex Sensor with Background Suppression
Serial number	000000000
MAC Address	54-4a-05-06-01-66
Real-time Ethernet status	offline
Device name	[offline]

[offline]

✓

✓


✓

77.37 mm

After establishing the connection, the overview page “Device general” is displayed.

**Device Name:** A unique device name can be freely assigned to each device via the PROFINET control. The device name is also displayed in the first line of the display. If no name is assigned, [offline] is displayed here.

## 9.4. Device Settings



### Network Settings

By clicking on “Send” the settings are saved. After interruption of the power supply, the network settings are applied.

### Network Reset

In a network reset, the network settings are reset to the factory settings. See chapter “6.2. Default Settings” on page 9. The settings are applied after interruption of the power supply. The Sensor settings remain unchanged.

### Display Settings

For functional description of display settings see chapter “7.2. Display” on page 12.

### Password

The password for the website is changed here. An additional window opens in which the new password can be entered.

## 9.5. Measured Value Settings



Sensors for your success

English

- General device
- Device settings
- Measured value settings
- Device test

### Measured value settings

Specified offset	0 <input type="text"/> μm	Send
		Teach-in
		Reset
Apply offset	Apply	
	Reset	
Set resolution	High	
Filter	1	
Lighting mode	DCM	
Illumination	1000 <input type="text"/>	Apply
Emitted light	ON	
Reset sensor settings	Reset	

[offline]

✓ ✓ ✓

76.66 mm

### Offset

**Default Offset:** Set default offset. By clicking on “Teach” the current measured value is adopted as the default value. By clicking on “Reset” the offset value is set to 0. By entering a value in the field and clicking on “Send” a freely selected value can be set as the offset value.

**Apply Offset:** Accept the offset value set in the default value as the measured value. By clicking on “Apply” the offset default value is adopted as the displayed measured value. By clicking on “Reset” the offset function is reset and the actual distance is displayed.

For functional description of offset see chapter “7.3. Offset” on page 13.

### Resolution

For functional description of resolution see chapter “7.4. Resolution” on page 14.

### Filter

For functional description of filter see chapter “7.5. Filter” on page 14.

### Exposure

For functional description of exposure see chapter “7.6. Exposure” on page 14.


### Emitted Light

For functional description of transmitted light see chapter “7.8. Laser” on page 15.

### Sensor Settings Reset

In a reset, the Sensor settings are reset to the factory setting. The network settings remain unchanged. For functional description of Sensor settings reset see chapter “7.13. Reset” on page 17.

## 9.6. Device Test



The screenshot shows the Wenglor web interface. At the top left is the Wenglor logo and the tagline "Sensors for your success". At the top right is a language dropdown menu set to "English". Below this is a blue navigation bar. On the left side of the main content area is a sidebar menu with the following items: "General device", "Device settings", "Measured value settings", and "Device test" (which is highlighted). The main content area is titled "Device test" and contains a form with the following fields: "Simulation of" (with a dropdown menu), "Measured Value" (with a text input field and a unit selector set to "µm" and an "Apply" button), "Warmup" (with a dropdown menu set to "Off"), "Signal" (with a dropdown menu set to "Off"), "Temperature" (with a dropdown menu set to "Off"), and "Test mode" (with a "Switch off" button). To the right of the form is a yellow status bar that says "[offline]". Below this is a black display window showing three green checkmarks and the text "75.99 mm".

For functional description of device test see chapter “7.9. I/O Test” on page 15.

The test is activated as soon as at least one parameter is changed.

The length of the test is limited to 10 minutes. Afterwards, the test is terminated automatically. The remaining time of the test is displayed under the button “Switch off” and below the display window. The test can also be terminated prematurely by clicking on “Switch off”.

## 10. Maintenance Instructions

- This wenglor Sensor is maintenance-free.
- It is recommended to clean the lens and the display regularly and to check the socket connections.
- Do not use any solvents or cleaning agents to clean the Sensor, which could damage the device.

## 11. Proper Disposal

wenglor sensoric gmbh does not take back unusable or irreparable products. When disposing of the products, the relevant national regulations for waste disposal apply.

## 12. EU Declaration of Conformity

The EU declaration of conformity can be found on our website at [www.wenglor.com](http://www.wenglor.com) in download area.