

## Installationsanleitung uniVision Decode/Patternmatch Offline-Lizenz

1. Stecken Sie den grünen USB USB-Dongel in einen freien USB-Port.



- 2. Stecken Sie den wenglor USB-Stick in einen weiteren freien USB-Port.
- 3. Starten Sie nun die uniVision-Software und öffnen Sie ein Projekt (z.B. Beispieldatei) im Offline-Betrieb. Verbinden Sie sich nicht zu einem Gerät.
- 4. Durch Klicken auf den Menüleisteneintrag "Hilfe" → "Lizenzen" öffnet sich das Lizenzfenster.

^	Modulname	Lizenzstatus	
	Modul 1D-Code	•	:
	Modul 2D-Code	•	
	🔠 Modul Mustervergleich	•	
	👰 Gerät Kamera	~	
	🌲 Gerät FTP	×	
	🌨 Gerät RS-232	~	

- 5. Auf "Laden" klicken und im Unterordner des wenglor USB-Sticks die entsprechenden Lizenzdateien auswählen.
- 6. Die Module, für die die Lizenzen hinzugefügt wurden, werden nun im Lizenzfenster als verfügbar angezeigt und können in Offline-Projekten verwendet werden.

Iodulliste: 127.0.0	.1:32001		
Mod	ulname	Lizenzstatus	*
🛒 Modul Clus	ter	~	
Modul 1D-	Code	~	
Modul 2D-	Code	~	E
🛱 Modul Koor	dinatensystem	~	
🔠 Modul Filte	r	~	
Modul Bildy	ergleich	~	
	e-1		-



## **HINWEIS!**

Die Nummer der Lizenzdatei muss identisch sein mit der Nummer, die sich auf dem grünen USB-Dongel befindet.



## Installation Instructions uniVision offline licenses for decode and pattern match modules

1. Plug the green USB dongle into a vacant USB port.



- 2. Plug the wenglor USB stick into another vacant USB port.
- 3. Start uniVision software and open a project (e.g. sample file) in the offline mode. Do not connect to a device.
- 4. After clicking "Licenses" under "Help" in the menu bar, the license window appears.

^	Module Name	License Status	-
	Module Code 1D	•	Ξ
	Module Code 2D	•	
	🔠 Module Pattern Match	•	
	Device Camera	×	
	Device FTP	×	
	Device RS232	~	
	A D · TOD	A	

- 5. Click "Load" and select the corresponding license files from the subdirectory on the wenglor USB stick.
- 6. The modules for which licenses have been added are now displayed as available in the license window and can be used in offline projects.

Module Name	License Status	
Kodule Cluster	~	
Module Code 1D	×	
Module Code 2D	~	:
😂 Module Coordinate System	~	
III Module Filter	~	
Module Image Comparison	×	
3		

## NOTE!

The license file's number must be identical to the number on the green USB dongle.