



P1NKxxx

Retro-Reflex Sensors for Transparent Objects



Operating Instructions

Table of Contents

1.	General	3
	1.1 Information Concerning these Instructions	3
	1.2 Explanations of Symbols	3
	1.3 Limitation of Liability	
	1.4 Copyrights	4
2.	For Your Safety	5
	2.1 Use for Intended Purpose	
	2.2 Use for Other than the Intended Purpose	5
	2.3 Personnel Qualifications	
	2.4 Modification of Products	
	2.5 General Safety Precautions	
	2.6 Approvals and protection class	6
3.	Technical Data	7
	3.1 Technical Data	
	3.1.1 Spot diameter	
	3.1.2 Smallest detectable part	
	3.1.3 Switching distance	
	3.2 Complementary Products	
	3.3 Layout	
	3.5 Scope of Delivery	
4.	Transport and Storage	
4.	4.1 Transport	
	4.2 Storage	
5.	Installation and Electrical Connection	
э.	5.1 Installation	
	5.2 Electrical Connection	
	5.3 Diagnostics	
6.	Settings	
7.	I/O-Link	14
8.	Maintenance Instructions	14
9.	Proper Disposal	14
10	Appendix	
	10.1 List of Abbreviations	
	10.2 Change Index, Operating Instructions	
	10.3 ELL Doclaration of Conformity	

1. General

1.1 Information Concerning these Instructions

- These instructions apply to the product with ID code P1NKxxx.
- They make it possible to use the product safely and efficiently.
- These instructions are an integral part of the product and must be kept on hand for the entire duration of its service life.
- · Local accident prevention regulations and national work safety regulations must be complied with as well.
- The product is subject to further technical development, and thus the information contained in these operating instructions may also be subject to change. The current version can be found at www.wenglor.com in the product's separate download area.



NOTE!

The operating instructions must be read carefully before using the product and must be kept on hand for later reference.

1.2 Explanations of Symbols

- · Safety precautions and warnings are emphasized by means of symbols and attention-getting words
- · Safe use of the product is only possible if these safety precautions and warnings are adhered to

The safety precautions and warnings are laid out in accordance with the following principle:



Attention-Getting Word! Type and Source of Danger!

Possible consequences in the event that the hazard is disregarded.

· Measures for averting the hazard.

The meanings of the attention-getting words, as well as the scope of the associated hazards, are listed below.



DANGER!

This word indicates a hazard with a high degree of risk which, if not avoided, results in death or severe injury.



WARNING!

This word indicates a hazard with a medium degree of risk which, if not avoided, may result in death or severe injury.



CAUTION!

This word indicates a hazard with a low degree of risk which, if not avoided, may result in minor or moderate injury.



ATTENTION!

This word draws attention to a potentially hazardous situation which, if not avoided, may result in property damage.



NOTE!

A note draws attention to useful tips and suggestions, as well as information regarding efficient, error-free use.

1.3 Limitation of Liability

- The product has been developed in consideration of the current state-of-the-art and applicable standards and guidelines. Subject to change without notice.
- A valid declaration of conformity can be accessed at www.wenglor.com in the product's separate download area.
- wenglor sensoric elektronische Geräte GmbH (hereinafter referred to as "wenglor") excludes all liability in the event of:
 - · Non-compliance with the instructions
 - · Use of the product for purposes other than those intended
 - · Use by untrained personnel
 - · Use of unapproved replacement parts
 - · Unapproved modification of products
- These operating instructions do not include any guarantees from wenglor with regard to the described procedures or specific product characteristics.
- wenglor assumes no liability for printing errors or other inaccuracies contained in these operating
 instructions, unless wenglor was verifiably aware of such errors at the point in time at which the operating
 instructions were prepared.

1.4 Copyrights

- · The contents of these instructions are protected by copyright law.
- · All rights are reserved by wenglor.
- Commercial reproduction or any other commercial use of the provided content and information, in particular graphics and images, is not permitted without previous written consent from wenglor.

4 General

2. For Your Safety

2.1 Use for Intended Purpose

The product is based on the following functional principle:

Retro-Reflex Sensors for Clear Glass Recognition

Reflex sensors for clear glass recognition can be adjusted so precisely that they can reliably recognize highly transparent objects such as glass, glass bottles or sheet products. Even shiny, chromed or reflective surfaces can be reliably detected thanks to the integrated polarization filter.

The transmitter and receiver are located in a single housing and require a reflector to work. The output switches if the light beam between the sensor and reflector is interrupted. The visible light spot of retro-reflex sensors facilitates adjustment and commissioning. Depending on the sensor type, even small objects up to 0.1mm can be reliably detected over long distances.

This product can be used in the following industry sectors:

- Special machinery manufacturing
 Consumer goods industry
- Heavy machinery manufacturing
- · Logistics
- Automotive industry
- · Food industry
- · Packaging industry
- Pharmaceuticals industry
- · Plastics industry
- Woodworking industry
- · Beverages industry

- Paper industry
- · Electronics industry
- · Glass industry
- · Steel industry
- · Aviation industry
- · Chemicals industry
- · Alternative energy
- · Raw materials extraction

2.2 Use for Other than the Intended Purpose

- Not a safety component in accordance with 2006/42/EC (Machinery Directive)
- The product is not suitable for use in potentially explosive atmospheres.
- The product may only be used with accessories supplied or approved by wenglor, or combined with approved products. A list of approved accessories and combination products can be accessed at www.wenglor.com on the product detail page.

DANGER!



Risk of personal injury or property damage in case of use for other than the intended purpose!

Use for other than the intended purpose may lead to hazardous situations.

· Observe instructions regarding use for intended purpose.

2.3 Personnel Qualifications

- · Suitable technical training is a prerequisite.
- · In-house electronics training is required.
- Trained personnel must have uninterrupted access to the operating instructions.



DANGER!

Risk of personal injury or property damage in case of incorrect initial start-up and


Personal injury and damage to equipment may occur.

· Adequate training and qualification of personnel.

2.4 Modification of Products

DANGER!






Personal injury and damage to equipment may occur. Non-observance may result in loss of the CE marking and the guarantee may be rendered null and void.

· Modification of the product is impermissible.

2.5 General Safety Precautions

NOTE!





- · In the event of possible changes, the respectively current version of the operating instructions can be accessed at www.wenglor.com in the product's download area.
- · Read the operating instructions carefully before using the product.
- · Protect the sensor against contamination and mechanical influences.

2.6 Approvals and protection class











6 For Your Safety

3. Technical Data

3.1 Technical Data

Order Number		P1NK		
Technical Data		202	206	
Optical Data				
Range		2,600 mm		
Reference reflector		RQ100BA		
Clear glass recognition		yes		
Switching hysteresis		< 5 %		
Light source		Red light		
Polarization filter		yes		
Service life (ambient temp. = +25° C)		100,0	000 h	
Max. permissible ambient light		10,00	0 Lux	
Single-lens optics		yes		
Spot diameter		See ta	able 1	
Smallest detectable part		See ta	able 2	
Electrical Data				
Supply power		1030	V DC	
IO-Link supply voltage		1830	V DC	
Current consumption (operating voltage =	= 24 V)	< 20		
Switching frequency		2000		
Switching frequency (speed mode)		3500 Hz		
Response time		0,25 ms		
Response time (speed mode)		0,14 ms		
Temperature drift		< 5		
Temperature range		-40(
Switching output voltage drop		< 2		
Switching output switching current		100		
Switching output residual current		< 50	•	
Short-circuit protection		ye		
Reverse polarity protected Overload-proof		ye		
Lockable		yes yes		
Interface		yes IO-Link		
IO-Link version		1.1		
Protection class				
Output PNP antivalent		×	1	
function NPN antivalent		^	×	
Connection Diagram No.		215	213	
Mechanical Data		213	213	
Setting method		Potentiometer		
Housing material		Plastic		
Degree of protection		IP67/IP68		
Connection		Plug M12; 4-pin		
Lens cover		PMMA		
Technical Safety Data				
MTTFd (EN ISO 13849-1)		2414 a		
. ,	· · · · · · · · · · · · · · · · · · ·			

3.1.1 Spot diameter

Working Distance	0,5 m	1,3 m	2,6 m
Spot diameter	30 mm	45 mm	80 mm

Table 1

3.1.2 Smallest detectable part

Distance, Sensor to Reflector	0,5 m	1,3 m	2,6 m
Smallest detectable part	1,5 mm	4 mm	15 mm

Table 2

3.1.3 Switching distance

Achievable switching distance depends on the utilized reflector. Nominal switching distance is achieved with reflector types RQ100BA. Achievable ranges for other reflectors are listed in the following tables:

Reflector	Range
RQ100BA	02,60 m
RE18040BA	01,50 m
RQ84BA	01,80 m
RR84BA	02,20 m
RE9538BA	00,85 m
RE6151BH	00,90 m
RE6151BM	02,00 m
RR50_A	01,55 m
RE6040BA	01,80 m
RE8222BA	01,10 m
RR34_M	01,20 m
RE3220BM	00,90 m
RE6210BM	00,50 m
RR25_M	00,65 m
RR25KP	00,35 m

Reflector	Range	
RR21_M	00,65 m	_
ZRME01B01	00,25 m	
ZRME03B01	01,10 m	_
ZRAE02B01	00,90 m	
ZRMR02K01	00,30 m	
ZRMS02_01	00,50 m	
ZRAF08K01	00,40 m	
ZRAF07K01	00,40 m	
ZRDF03K01	01,30 m	
ZRDF10K01	01,40 m	
RF505	00,40 m	
RF255	00,40 m	
RF508	00,40 m	
RF258	00,40 m	
RF4050	00.30 m	




NOTE!

• In order to increase the stability in the detection of highly transparent objects, it is recommended to use reflectors with microstructure.


8 Technical Data

3.2 Complementary Products

wenglor can provide you with suitable connection technology for your product.




3.3 Layout



3.4 Control Panel





05 = switching distance adjuster

30 = switching status indicator / contamination warning

68 = supply power indicator

3.5 Scope of Delivery

- Sensor
- · Safety precautions
- · Mounting-Set 02

4. Transport and Storage

4.1 Transport

Upon receipt of shipment, the goods must be inspected for damage in transit. In the case of damage, conditionally accept the package and notify the manufacturer of the damage. Then return the device, making reference to damage in transit.

4.2 Storage

The following points must be taken into condition with regard to storage:

- · Do not store the product outdoors.
- · Store the product in a dry, dust-free place.
- · Protect the product against mechanical impacts.
- · Protect the product against exposure to direct sunlight.

ATTENTION!



Risk of property damage in case of improper storage!

The product may be damaged.

· Storage instructions must be complied with.

5. Installation and Electrical Connection

5.1 Installation

- Protect the product from contamination during installation.
- · Observe all applicable electrical and mechanical regulations, standards, and safety rules.
- · Protect the product against mechanical influences.
- · Make sure that the sensor is mounted in a mechanically secure fashion.
- Specified torque values must be complied with (see section "3.2 Layout", page 9).

ATTENTION!



Risk of property damage in case of improper installation!

The product may be damaged.

· Installation instructions must be complied with.

CAUTION!





Risk of personal injury or property damage during installation!

Personal injury and damage to the product may occur.

A safe installation environment must be assured.

5.2 Electrical Connection





+ Supply Voltage + - Supply Voltage 0 V - Supply Voltage (AC Voltage) A Switching Output (NC) V Contamination/Error Output (NO) Contamination/Error Output (NC) E Input (analog or digital)
Supply Voltage (AC Voltage) A Switching Output (NO) Contamination/Error Output (NO) Contamination/Error Output (NO) Input (analog or digital)
A Switching Output (NO) Ä Switching Output (NC) V Contamination/Error Output (NO) V Contamination/Error Output (NC) E Input (analog or digital)
Switching Output (NC) Contamination/Error Output (NO) Contamination/Error Output (NC) Input (analog or digital)
V Contamination/Error Output (NO) ▼ Contamination/Error Output (NC) E Input (analog or digital)
Contamination/Error Output (NC) Input (analog or digital)
E Input (analog or digital)
T Teach Input
Z Time Delay (activation)
s Shielding
RxD Interface Receive Path
TxD Interface Send Path
RDY Ready
GND Ground
CL Clock
E/A Output/Input programmable
IO -Link
PoE Power over Ethernet
IN Safety Input
OSSD Safety Output
Signal Output
BI_D+/- Ethernet Gigabit bidirect. data line (A-D)
ENORSEZ Encoder 0-pulse 0-0 (TTL)

PT	Platinum measuring resistor
nc	not connected
U	Test Input
Ū	Test Input inverted
W	Trigger Input
W -	Ground for the Trigger Input
0	Analog Output
0-	Ground for the Analog Output
BZ	Block Discharge
A _M v	Valve Output
а	Valve Control Output +
b	Valve Control Output 0 V
SY	Synchronization
SY-	Ground for the Synchronization
E+	Receiver-Line
S+	Emitter-Line
÷	Grounding
SnR	Switching Distance Reduction
Rx+/-	Ethernet Receive Path
Tx+/-	Ethernet Send Path
Bus	Interfaces-Bus A(+)/B(-)
La	Emitted Light disengageable
Mag	Magnet activation
RES	Input confirmation
EDM	Contactor Monitoring

	_
ENAR5422	Encoder A/Ā (TTL)
ENBRS422	
ENA	Encoder A
ENB	Encoder B
Amin	Digital output MIN
Амах	Digital output MAX
Аок	Digital output OK
SY In	Synchronization In
SY OUT	Synchronization OUT
OLT	Brightness output
М	Maintenance
rsv	reserved
Wire Co	olors according to IEC 60757
BK	Black
BN	Brown
RD	Red
RD OG	Red Orange
OG	Orange
OG YE	Orange Yellow
OG YE GN	Orange Yellow Green
OG YE GN BU	Orange Yellow Green Blue
OG YE GN BU VT	Orange Yellow Green Blue Violet
OG YE GN BU VT GY WH	Orange Yellow Green Blue Violet Grey

DANGER!



Risk of personal injury or property damage due to electric current!

Voltage conducting parts may cause personal injury or damage to equipment.


• The electric device may only be connected by appropriately qualified personnel.

5.3 Diagnostics


Causes for Triggering the Contamination Warning (blinking LED):

Display LED	Diagnosis/Cause	Elimination
	Contamination	Carefully clean the optic cover with a cloth.
Continuous blinking	Aged emitter diode	Replace the sensor.
at approx. 2.5 Hz	Unreliable working range	Increase the sensor's switching distance. Reduce distance between sensor and reflector.
	Short-circuit	Check electrical wiring and eliminate the short-circuit.
Continuous blinking at approx. 5 Hz	Over-temperature	Disconnect the sensor from supply power and allow it to cool down.
	Hardware error	Replace the sensor.


Contamination Warning Flowcharts



beginning contamination



advanced contamination



Required action in case of fault:

NOTE!

- · Shut down the machine.
- i
- Analyze and eliminate the cause of error with the help of the diagnostics information.
- If the error cannot be eliminated, please contact wenglor's support department.
- Do not operate in case of indeterminate malfunctioning.
- The machine must be shut down if the error cannot be unequivocally clarified or reliably eliminated.

DANGER!



Risk of personal injury or property damage in case of non-compliance!

The system's safety function is disabled. Personal injury and damage to equipment.

· Required action as specified in case of fault.

6. Settings

- · Align the sensor to the reflector.
- · Make sure that the sensor and the reflector are mounted in a mechanically secure fashion.
- · Turn the potentiometer all the way to the left.
- · Turn the potentiometer clockwise until the output is switched.
- · Continue to turn up the potentiometer until the LED no longer blinks.
- · Move the object into the light barrier and check for correct functioning.

7. I/O-Link

Further settings are possible via the IO-Link interface. The IODD can be found at www.wenglor.com in the product's download area.

8. Maintenance Instructions

NOTE!



- · This wenglor sensor is maintenance-free.
- · Cleaning and inspection of the plug connections at regular intervals are advisable.
- · Do not clean the sensor with solvents or cleansers which could damage the product.
- The product must be protected against contamination during initial start-up.

9. Proper Disposal

wenglor sensoric GmbH does not accept the return of unusable or irreparable products. Respectively valid national waste disposal regulations apply to product disposal.

14 Settings

10. Appendix

10.1 List of Abbreviations

Abbreviation	Meaning	
Tu	Ambient temperature	
Ub	Supply voltage	
IODD	IO Device Description	
MTTFd	Mean Time to Dangerous Failure	

10.2 Change Index, Operating Instructions

Version	Date	Description/Change
1.0.0	25.07.18	Initial version of the operating instructions

10.3 EU Declaration of Conformity

The EU declaration of conformity can be found on our website at www.wenglor.com in the product's download area.